

ご購入いただいたお客様へのお願い Request to customers who have purchased.

このたびは「ポケモン ポケなで モンスターボール」をご購入いただき誠にありがとうございます。

本商品をより良く遊んでいただくために、遊ぶ前に下記のような操作をお願いいたします。

Thank you for purchasing "Pokémon Friends Poké Ball". To ensure you get the most out of this, please follow the steps below before playing.

はじめて遊ぶ前に： Before playing for the first time:

電池を入れ、「タイトル画面」が表示されたら必ずリセットボタンを押してください。
Please insert the batteries and when the "Title screen" appears, be sure to press Reset button.




リセットボタンを押した後、決定ボタンを長押しすると電源がオンになります。
After pressing Reset button, press and hold Confirm button to turn the power on.

こんなときは…

Troubleshooting

- 電源をオンにするたびに毎回「時計リセット画面」が表示されてしまう。

Every time you turn on the power, "Clock reset screen" appears.



- ・メニューの「せってい」から「データしょうきょ」を行い、電池をいれたまま再度最初から遊んでください。

- Please go to "Settings" in the menu and select "Delete Save Data", then start playing again from the beginning with the battery inserted.

※「データしょうきょ」の方法はWEB遊び方説明書の19ページを確認してください。
Please refer to page 19 of Online How to Play Instruction Manual for how to "Delete Save Data".

※「データしょうきょ」を行うとつかまえたポケモン、トレーナーレベル、なかよし度などすべてのデータが消えてしまいます。あらかじめご了承ください。

If you delete the data, all data will be deleted, including Pokémon you've caught, your Trainer Level, and Friendship Level. Thank you for your understanding in advance.



For children age 4 and up

TAKARA TOMY

Pokémon Friends Poké Ball

*Please understand that any mobile data or internet usage fees incurred in using this instruction manual are the responsibility of the customer.

[Online How to Play
Instruction Manual](#)



**REQUIRES 4 LR03 ("AAA" SIZE)
BATTERIES (NOT INCLUDED.)**

- *The photos and any associated visual effects are for reference only.
- *This product is not a touch panel screen.
- *Photos and illustrations may differ slightly from the actual product.

© Nintendo, Creatures, GAME FREAK, TV Tokyo, ShoPro, JR Kikaku. © Pokémon. TM, ®, and character names are trademarks of Nintendo.

Contents

- Device x1
- User manual (Japanese) x1
- User manual (English) x1



Warning

Parents and guardians, please read this.

- This product contains small parts. There is a possibility of swallowing or choking, so please keep away from children under 3 years of age.

Caution

- Before using this product, please make sure to read this user manual and the online how to play instruction manual.
- Please use this product in a well lit environment and avoid keeping your eyes too close to the display.
- If you are sensitive to bright light or flashing lights, stop using this product immediately and consult with a doctor.
- Your eyes may feel tired or uncomfortable, so avoid using this product for extended periods of time and take breaks regularly.
- For small children, it may be difficult for them to realize that their eyes are becoming tired or uncomfortable, so please take care. If in any case you experience symptoms like dizziness, nausea, or motion sickness, stop using this product immediately. If negative symptoms persist, please see a doctor.
- Please do not use this product while walking. It may result in an accident or injury.
- Glass is used for the LCD screen. Do not push strongly on the screen, hit the screen, or use this product in a reckless manner.
- Since it may result in an accident or injury, please store this product in a place safe from children under 3 years of age when you are finished using it.
- Using batteries incorrectly can result in fire, explosion, and leaking liquid. Please take note of the following.
 - Do not use rechargeable batteries.
 - Do not use old batteries together with new batteries or mix multiple different types of batteries together.
 - Set the batteries in the correct +/- (plus/minus) position.
 - When you are finished using the device, make sure to turn the power off and remove the batteries.
 - Do not short, dismantle, or heat the batteries. Do not put them near or inside of fire.
 - If in any case liquid from the batteries gets into your eyes, wash them immediately with lots of water and consult with a doctor. If the liquid gets on your skin or clothes, wash it with water.
 - When discarding the batteries, follow the instructions for disposal in accordance with your local government.
- Do not throw.
- Do not cover your face with plastic bags or put them on your head.


<Request> ○ This device uses sensitive electronic parts. Do not get it wet, dirty, or take it apart. ○ The plastic bags are for packaging purposes only. Please discard them immediately. ○ Do not hit or drop the device. ○ Do not place or store the device in direct sunlight, a hot vehicle, near a heater, or anywhere that the temperature is very hot or very cold. It may result in malfunctions. ○ Do not place or store the device in a very humid place or somewhere with a lot of dust. It may result in a fire or electric shock. ○ Please understand that we cannot take responsibility for data that has been lost. ○ Do not wipe the device with thinner, benzene, or other types of alcohol. To clean the device, wipe it lightly with a dry cloth.

Contents

1 Device: On/Off	3
2 Inserting batteries	3
3 Basic controls	4
4 Partner Pokémon and Friend Pokémon	4
When playing for the first time	5
Home screen	6
● Lock screen ● Home screen	6
● How to use Pokémon Friends Poké Ball	7
● Call and play ● Time for bed	8
◆ Partner Pokémon	9
Menu	10
1. Care	11
● Bake a Cake	11
● Wash ● Give a Berry	12
2. Play	13
● Hide and Seek ● Sing Together	13
3. Pokémon Battle	14
4. Friend List	15
■ Introducing the Pokémon included!	16
5. Diary	17
6. Settings	18
Troubleshooting • • •	20

1

Device: On/Off



ON ...Hold Confirm button for at least 3 seconds

OFF ...On the Home screen, hold Confirm button for at least 3 seconds

Back ...Anywhere but the Home screen, hold Confirm button for at least 2 seconds


Auto power off

If there is no input for 3 minutes, the power will turn off.

2

Inserting batteries

- 1 Remove the screws from the bottom of the device with a Phillips screwdriver.
- 2 Check the plus minus location for the batteries and insert four AAA alkaline batteries (sold separately) before putting the battery cover back on.
- 3 When removing the batteries, perform these steps in reverse.



When the battery replacement symbol appears (pictured to the left), it means the batteries are running low. Please replace the batteries.

***When replacing batteries, always make sure that power to the device has been turned off. If batteries are removed while the screen is displayed, your save data may be deleted.**

***Replace all batteries with new batteries.**



3

Basic controls

●Left button

Move left



●Confirm button

Confirm

●Hold the Confirm button

Go back



Reset button

The device will reset and restart.

Push the button with a long thin object.

Data will not be lost even if you reset.

If there are new batteries in the device but it is not operating normally, reset the device.

●Right button

Move right



Screen input display



Push the Confirm button



Stroke the red part of the device in wide strokes



Push the buttons that are glowing green

4

Partner Pokémon and Friend Pokémon

●Partner Pokémon (7 in total)



Their expression changes as you spend time with them, and they will speak to you!

●Friend Pokémon (150 in total)



They have one expression, but you can play with them just like your Partner Pokémon!

**When playing for the first time, the tutorial will begin!
After powering on, follow the instructions on screen and have fun!**

When playing for the first time (tutorial)

- 1 Insert the batteries and hold the Confirm button to start!
Follow the instructions on screen and press the Confirm button to continue!



- 2 ●Language
You can choose to play in English or Japanese.
Press the Left or Right button and then the Confirm button to select the language!



- 3 ●Name
Set up your Name (Trainer Name)! Use the Left and Right buttons to select characters and the Confirm button to input them!
When you're done, press OK to continue!



- 4 ●Hand Color
You can choose the color of your hand when you pet your Pokémon. Use the Left and Right buttons and then the Confirm button to select your Hand Color!



- 5 ●Clock
Set the time! Use the Left and Right buttons and then the Confirm button to select the number you want to change!
You can increase or decrease the number with the Left and Right buttons. Press the Confirm button when you're done!
When the time is set, press OK to continue!




When you're done setting up, a hungry Pikachu will appear! Follow the instructions on screen and bake a cake for Pikachu! You can catch Pikachu if you get along with it well!

**Once you're able to catch Pikachu, your life with Pokémon will begin!
Catch lots of Pokémon and become good friends with them!**

Home screen

● Lock screen

If you turn the power on after finishing the tutorial, the device will start from the Lock screen!



● Home screen

• When you have selected a Partner Pokémon (7 in total)

Partner Pokémon

Its movements will change as your Friendship Level increases! Let's be good friends!



Friendship Level

This is how well you are getting along with your current Partner Pokémon

If you have caught multiple Partner Pokémon, you can switch between different Partner Pokémon with the Left and Right buttons.

- Press the Confirm button to open the Menu
- Hold the Confirm button to turn the power off

• When you have selected a Friend Pokémon (150 in total)

Partner Pokémon

Friendship Level

This is how well you are getting along with your current Friend Pokémon



Speech bubble

This will change depending on how well you are getting along with your Friend Pokémon

Friend Pokémon

● The expression of Friend Pokémon will not change.

● How to use Pokémon Friends Poké Ball

You can stroke your Pokémon by stroking the red part on top of the device while on the Home screen!

Stroking vertically and horizontally

Stroke the red part on top of the device slowly in a vertical or horizontal motion! The Pokémon will react happily!



Did you call?

If you pat your Pokémon quickly on the red part on top of the device twice it might just look your way?!



Nap Time

If you slowly pat your Pokémon repeatedly on the red part on top of the device, the Pokémon might take a nap?! Pat them again to wake them up!



● Friend Pokémon will not take naps

Maybe if you stroke your Pokémon at different speeds or in different ways, it might affect your Friendship Level differently?! Try stroking lots of different Pokémon!

If you get a good reaction from your Pokémon, tell your friends about it and share it with

#Pokémon Friends Poké Ball !!

● Call and play

When you're done playing and the power is turned off, Pokémon might call you asking to play! Respond by pressing the Confirm button or stroking them!




● You can turn off Call to Play in settings.

● Time for bed (9pm to 5:59am)

Pokémon are sleeping at night. You should rest well too! When you want to play, touch the red part on the top of the device or press the Confirm button and your Pokémon will wake up to play!



Enjoy life with your Pokémon!



◆ Your Partner Pokémon's expression will change depending on your Friendship Level

Pikachu



Eevee



Sprigatito



Fuecoco



Quaxly



Lucario



Sylveon



Menu

Choose how you want to play with the Left and Right buttons and press the Confirm button to select.

1. Care



You can bake a cake for your Pokémon, wash your Pokémon, give them berries and take care of them!

2. Play



You can play Hide and Seek with your Pokémon and sing songs with them!

3. Pokémon Battle



You can battle with wild Pokémon and Friend Pokémon together with your selected Pokémon!

4. Friend List



You can check information about the Pokémon you've caught and select your Partner Pokémon or Friend Pokémon!

5. Diary



A log of your daily activities is recorded automatically! Check what you played with your Pokémon!

6. Settings



You can adjust the volume and screen brightness or delete your save data!





1. Care

Choose how you want to play with the Left and Right buttons and press the Confirm button to select.



● Bake a Cake



Bake a cake for your Pokémon! Mix during the time limit and cool the cream for a more delicious cake!

[Mixing Turn]

Mix the cream by stroking the red part on top of the device repeatedly! How fast can you do it?



Stroke the red part of the device in wide strokes



[Cooling Turn]

Press the Left button and Right button alternately to cool the cream! How fast can you cool it?



Press the Left and Right buttons alternately



Based on the result of your play, the cake you made will change!



When the mark to the left appears from your Pokémon on the Home screen, it means they want some cake!

● You can only play with the same Pokémon once per day!

● Wash



[Start] First let's make bubbles! You can make bubbles by stroking the top of the device! Let's quickly make lots of bubbles!



Stroke the red part of the device in wide strokes



[Finish] Press the Left button and Right button alternately to wash off the bubbles! You're done once they're all gone!



Press the Left and Right buttons alternately



When the mark to the left appears from your Pokémon on the Home screen, it means they want to take a bath!

● You can only play with the same Pokémon once per day!

● Give a Berry



When the berry is in front of your Pokémon, press the Confirm button to give the berry to your Pokémon! If you time it right, you can keep giving them berries! See how many berries you can give them!



[good timing]



[bad timing]



Press the Confirm button with good timing



2. Play

Choose how you want to play with the Left and Right buttons and press the Confirm button to select.



● Hide and Seek



The Pokémon will hide behind the boxes! The boxes will move. Use the Left and Right buttons and then the Confirm button and find your Partner Pokémon or Friend Pokémon! Each time you succeed, it will get harder! Try to set a record!



Select with the Left and Right buttons and press the Confirm button to decide

● Sing Together



When the Button mark that comes from the right arrives on top of the Note mark, press the same button as the Button mark! You lose if you miss 3 times! Each time you succeed, it will get harder! How far can you get?

Misses



Instrument mark

Button mark

Button-mark



Left button



Right button



Confirm button



Press the Left, Right, and Confirm buttons with good timing



3. Pokémon Battle

Battle together with your selected Partner Pokémon or Friend Pokémon! Your opponent is wild Pokémon, Partner Pokémon, or Friend Pokémon!

Press the Confirm button repeatedly to increase your Gauge, and win by getting your Gauge to MAX! Your opponent will attack you too!



Press the Confirm button repeatedly



Gauge

MAX

When your Pokémon uses its Special Move, your Gauge will reach MAX and you can win the battle! The higher your Friendship Level, the easier it is to use your Special Move! *Be careful! If your opponent uses its Special Move, your Gauge will drop!



If you defeat wild Pokémon, you can catch them!





4. Friend List



Check your success rate!

You can check your records for Pokémon battles, taking care of your Pokémon, and playing with your Pokémon! What games are you good at? Continue by pressing the Confirm button!



Select your Pokémon!


Choose what Pokémon you want to learn more about with the Left and Right buttons and device with the Confirm button.

- *Partner Pokémon will come first!
- *Friend Pokémon are listed in alphabetical order!
- *You can move the list faster by holding down the Left or Right button.
- *Only Pokémon you have caught will be displayed.



Learn about your Pokémon!

You can check information about the Pokémon you've caught!





Introducing the Pokémon included!

As you battle with your Pokémon, get along better with your Partner Pokémon, catch more Friend Pokémon, increase your Trainer Level, and play and take care of your Pokémon, more Pokémon will appear!

- | | | |
|---|--|--|
| <input type="checkbox"/> Pikachu : You'll find them when you first start playing | <input type="checkbox"/> Chandelure | <input type="checkbox"/> Ho-Oh |
| <input type="checkbox"/> Eevee : You'll find them when you reach Trainer Level 10 | <input type="checkbox"/> Grovyle | <input type="checkbox"/> Salamence |
| <input type="checkbox"/> Sprigatito : You'll find them when you reach Trainer Level 5 | <input type="checkbox"/> ?????? | <input type="checkbox"/> Greavard |
| <input type="checkbox"/> Fuecoco : You'll find them when you have a Pokémon battle from the first day | <input type="checkbox"/> Toxtricity (Low Key Form) | <input type="checkbox"/> Piplup |
| <input type="checkbox"/> Quaxly : You'll find them from the second day onward | <input type="checkbox"/> Squirtle | <input type="checkbox"/> Ponyta (Galarian Form) |
| <input type="checkbox"/> Lucario : You'll find them in a Pokémon battle on the day after you catch Fuecoco | <input type="checkbox"/> Frigibax | <input type="checkbox"/> Porygon-Z |
| <input type="checkbox"/> Sylveon : You'll find them from the third day onward | <input type="checkbox"/> Xerneas | <input type="checkbox"/> Meowscarada |
| <input type="checkbox"/> Maushold (Family of Four) | <input type="checkbox"/> ?????? | <input type="checkbox"/> ?????? |
| <input type="checkbox"/> Yveltal | <input type="checkbox"/> Ceruledege | <input type="checkbox"/> Delphox |
| <input type="checkbox"/> Palafin (Hero Form) | <input type="checkbox"/> Zoroark | <input type="checkbox"/> Alcremie (Vanilla Cream) |
| <input type="checkbox"/> Rockruff | <input type="checkbox"/> Spheal | <input type="checkbox"/> Marill |
| <input type="checkbox"/> Inteleon | <input type="checkbox"/> Chikorita | <input type="checkbox"/> Mudkip |
| <input type="checkbox"/> Arcanine | <input type="checkbox"/> Medicham | <input type="checkbox"/> Mimikyu (Disguised Form) |
| <input type="checkbox"/> Quaquaval | <input type="checkbox"/> Minccino | <input type="checkbox"/> Buneary |
| <input type="checkbox"/> Wooper | <input type="checkbox"/> Altaria | <input type="checkbox"/> ?????? |
| <input type="checkbox"/> Cinderace | <input type="checkbox"/> Shuckle | <input type="checkbox"/> Mewtwo |
| <input type="checkbox"/> Espeon | <input type="checkbox"/> Dialga | <input type="checkbox"/> Miraidon |
| <input type="checkbox"/> Elekid | <input type="checkbox"/> Tinkaton | <input type="checkbox"/> Milotic |
| <input type="checkbox"/> Toxel | <input type="checkbox"/> Dedenne | <input type="checkbox"/> Misdreavus |
| <input type="checkbox"/> Furret | <input type="checkbox"/> Hattrem | <input type="checkbox"/> Metagross |
| <input type="checkbox"/> Glalie | <input type="checkbox"/> Terapagos (Normal Forme) | <input type="checkbox"/> Ditto |
| <input type="checkbox"/> Noivern | <input type="checkbox"/> Ampharos | <input type="checkbox"/> Rowlet |
| <input type="checkbox"/> Noibat | <input type="checkbox"/> Clodsire | <input type="checkbox"/> Morpeko (Full Belly Mode) |
| <input type="checkbox"/> Kyogre | <input type="checkbox"/> Togepi | <input type="checkbox"/> Slowpoke |
| <input type="checkbox"/> Dragonite | <input type="checkbox"/> Dragapult | <input type="checkbox"/> Sableye |
| <input type="checkbox"/> Snorlax | <input type="checkbox"/> Dreepy | <input type="checkbox"/> Pancham |
| <input type="checkbox"/> Garchomp | <input type="checkbox"/> Pyukumuku | <input type="checkbox"/> Snom |
| <input type="checkbox"/> Blastoise | <input type="checkbox"/> Finizen | <input type="checkbox"/> Greedent |
| <input type="checkbox"/> Charcadet | <input type="checkbox"/> Meowth | <input type="checkbox"/> Skeledirge |
| <input type="checkbox"/> Bewear | <input type="checkbox"/> Espurr | <input type="checkbox"/> Lapras |
| <input type="checkbox"/> Aegislash (Shield Forme) | <input type="checkbox"/> Sneasel | <input type="checkbox"/> Leafeon |
| <input type="checkbox"/> Cubchoo | <input type="checkbox"/> Goomy | <input type="checkbox"/> Riolu |
| <input type="checkbox"/> Groudon | <input type="checkbox"/> Goodra | <input type="checkbox"/> Charizard |
| <input type="checkbox"/> Glaceon | <input type="checkbox"/> Komala | <input type="checkbox"/> Lugia |
| <input type="checkbox"/> Armarouge | <input type="checkbox"/> Pawmot | <input type="checkbox"/> Rayquaza |
| <input type="checkbox"/> Greninja | <input type="checkbox"/> Blaziken | <input type="checkbox"/> Luxray |
| <input type="checkbox"/> Gengar | <input type="checkbox"/> Pachirisu | <input type="checkbox"/> Vulpix (Alola Form) |
| <input type="checkbox"/> Magikarp | <input type="checkbox"/> Pincurchin | <input type="checkbox"/> Vulpix |
| <input type="checkbox"/> Infernape | <input type="checkbox"/> Fidough | <input type="checkbox"/> Rotom |
| <input type="checkbox"/> Cosmog | <input type="checkbox"/> Pawmi | <input type="checkbox"/> Totodile |
| <input type="checkbox"/> Psyduck | <input type="checkbox"/> Chespin | <input type="checkbox"/> Yamper |
| <input type="checkbox"/> Koraidon | <input type="checkbox"/> Palkia | |
| <input type="checkbox"/> Gimmighoul (Roaming Form) | <input type="checkbox"/> Tyranitar | |
| <input type="checkbox"/> Munchlax | <input type="checkbox"/> Pichu | |
| <input type="checkbox"/> Gardevoir | <input type="checkbox"/> Clefairy | |
| <input type="checkbox"/> Scream Tail | <input type="checkbox"/> Charmander | |
| <input type="checkbox"/> Hydreigon | <input type="checkbox"/> Cyndaquil | |
| <input type="checkbox"/> Zacian (Crowned Sword) | <input type="checkbox"/> Teddiursa | |
| <input type="checkbox"/> Zamazenta (Crowned Shield) | <input type="checkbox"/> Talonflame | |
| <input type="checkbox"/> Grookey | <input type="checkbox"/> Moltres | |
| <input type="checkbox"/> Zapdos | <input type="checkbox"/> Flareon | |
| <input type="checkbox"/> Jolteon | <input type="checkbox"/> Bulbasaur | |
| <input type="checkbox"/> ?????? | <input type="checkbox"/> Venusaur | |
| <input type="checkbox"/> Zygarde (10% Forme) | <input type="checkbox"/> Flygon | |
| <input type="checkbox"/> Tatsugiri (Curly Form) | <input type="checkbox"/> Umbreon | |
| <input type="checkbox"/> Tatsugiri (Droopy Form) | <input type="checkbox"/> Articuno | |
| <input type="checkbox"/> Tatsugiri (Stretchy Form) | <input type="checkbox"/> Jigglypuff | |
| <input type="checkbox"/> Vaporeon | <input type="checkbox"/> Poipole | |

When you catch a Pokémon you like, tell your friends about it and share it with #Pokémon Friends Poké Ball !!

● If you have satisfied the conditions for multiple Pokémon to appear, certain Pokémon may not appear until you have obtained other Pokémon.



5. Diary

What you played will be recorded automatically! What kind of memories have you made with your Pokémon?



It starts with the cover!



Things that have happened will be written in the Diary! Press the Right button to go to the next page and the Left button to go to the previous page!

Your Trainer Level at the time

Your Friendship Level at the time

What Pokémon you played with

What games you played



How many days have passed since you started playing

- Only one page is saved in the Diary for each day
- Depending on the activity, some contents may not be recorded
- If there is too much data in the Diary, the oldest contents will be overwritten






6. Settings

Choose what you want to change with the Left and Right buttons and press the Confirm button to select.



Call

You can turn Call to Play (P8) on or off! Choose with the Left and Right buttons and use the Confirm button to decide.




Sound

You can change the volume. Adjust the volume with the Left and Right buttons and use the Confirm button to decide.



Clock

Change the time! Use the Left and Right buttons and then the Confirm button to select the number you want to change. You can increase or decrease the number with the Left and Right buttons! When the time is set, press OK.



Language

You can choose whether to play in English or Japanese. Choose with the Left and Right buttons and use the Confirm button to decide.





Brightness

You can change the screen brightness. Choose with the Left and Right buttons and use the Confirm button to decide.



Hand Color

You can choose the Hand Color for when you stroke your Pokémon. Choose with the Left and Right buttons and use the Confirm button to decide.



Name

Change your Name (Trainer Name)! Choose characters with the Left and Right buttons and use the Confirm button for input! When you're done, press OK.






- Hiragana
- Katakana
- Alphanumeric characters
- Backspace
- Confirm



Delete Save Data

Follow the instructions on screen if you want to delete all save data and return the device to factory default settings.



Troubleshooting

I can't seem to stroke well.	Refer to how to stroke your Pokémon on page 7 and rub the red part on the top of the device in wide strokes vertically or horizontally.	The sound is too quiet, or I can't hear any sound.	Set the volume of Sound in Settings to a higher value. If the volume is set to the lowest value, no sound will play. It is possible that the batteries may also be running low, so try replacing them with new batteries.
I want to turn off the function to receive calls to play from Pokémon.	Press the Confirm button on the Home screen to open the menu and turn Call off in Settings.	The batteries run out immediately.	When you're done playing, make sure to turn the power off. You may be able to extend battery life by reducing the brightness or volume in Settings.
The screen won't turn on.	Reinsert the batteries and push the reset button. If the issue is still not resolved, the batteries may be running low. Replace them with new batteries.		

発売元：株式会社 タカラトミー

〒124-8511 東京都葛飾区立石 7-9-10

タカラトミーでは「子どもたちに安全で楽しいおもちゃと夢を」を第一に考えております。そのため、常に製品に対し研究、改良を行っており、お買い上げ時期によって同一製品の中にも多少異なるものや、パッケージの写真やイラストなどと異なる場合がございますがご了承ください。製品につきましては、万全の注意をはらって製造に当たっておりますが、万一お気付きの点がございましたら下記までご連絡ください。

タカラトミーグループ お客様相談室 おかけ間違いのないようご注意ください

製品の修理などについては下記お客様相談室までお問い合わせください

 **0570-041031** 電話受付時間 10～17時
月曜日～金曜日（土日・祝日を除く）

タカラトミーサポート 検索 

本製品のお客様サポートは日本国内でのご購入かつ日本国内からのお問い合わせに限ります。

(Customer service is only available in case this product purchased in Japan and inquired from Japan domestic.)

● たのしいタカラトミーの情報はインターネットで www.takaratomy.co.jp

© TOMY

